Service booklet

VY, Monaro & WK series models

V6 engines (except cars fitted with LPG)

This supplement provides the service schedule and coupons for VY, Monaro and WK models fitted with V6 engines (except if converted to LPG).

V8 engines and V6 engines that have been converted to LPG have a different schedule of servicing, for which a different service supplement is used.

This supplement, should be kept, together with the Owner's Handbook, in the glovebox of your car.

HOLDEN

www.holden.com.au

Owner's Name .....

Address .....

Town .....

State.....Postcode .....

Model Name .....

Reg. No.....Eng. No. .....

Odometer Reading .....

Date of Purchase .....

(17 character I.S.O.V.I.N.) Vehicle Identification Number

Vehicle Identification Certificate

Selling Retailer's
Stamp & Signature .....

Holden Ltd, ABN 84 006 893 232 (hereinafter Holden).

Change of name, address or ownership

In the event of a Safety Recall, or for various reasons, Holden may need to contact you as the owner of this car. Also, if less than three years old, this car will qualify for Roadside Assistance, refer Chapter 9 of your Owner's Handbook. If you have recently changed your address, or name, or purchased this car second-hand, please help us to help you by taking a few minutes to fill in and mail the form on the third page of your Owner's Handbook.

© 2003 Holden Ltd. Reproduction in whole or part is prohibited without written approval from Holden Ltd, ABN 84 006 893 232.

Printed in Australia

Part No. 92158817
February 2003 (V & W, Print 1)

Contents

Service intervals 2
- 15,000km/9 months service intervals
- Distance based service intervals
- Service reminder message
- The free first service
- Service coupons
- Your Holden Retailer
- Warranty and service

Additional service requirements 4
- The conditions
- Additional services required
- Coupons for additional services

Maintenance Schedule 7

Service charges 10

Service coupons 13

15,000km /9 MONTH SERVICE INTERVALS

Distance/ time based service intervals

The first service is due at 1,500km or 1 month (whichever occurs first), then at 15,000km or 9 months (whichever occurs first), and then at every 15,000km or 9 months since the last service (whichever occurs first) thereafter.

The maintenance schedule for your vehicle is based on driving at least 15,000km in 9 months. Additional service are required under certain driving conditions, such as when towing, refer page 4.

In addition, if you drive less than 15,000km in 9 months some oils have to be changed more frequently. Engine oil can deteriorate faster than normal if engine operation is significantly hotter or colder than typical conditions or if driving in unusual environments (eg. high dust levels). Refer to page 4 for more information about driving conditions requiring additional service requirements.

Service reminder message

A service reminder message is built into the trip computer.

The reminder message first appears 1,000 km before the service is actually due, giving you time to arrange for the service to be carried out. The message shows on the trip computer for 10 seconds whenever the vehicle's ignition is switched ON or OFF, until the trip computer is reset. When the service is overdue the message flashes for 10 seconds when the ignition is turned ON or OFF.

- **1,500 km** Service shows when the car has travelled 500km since it was built.
- **15,000 km** Service shows when the car has travelled 14,000km since it was built.
- **30,000 km** Service shows when the car has travelled 29,000km since it was built.
- **45,000 km** Service shows when the car has travelled 44,000km since is was built etc.

The trip computer will be reset for you by your Holden Retailer when you take the car in to be serviced. If, for some reason, you wish to reset the reminder message yourself, follow the sequence below:

1. Turn the ignition OFF.
2. Hold down the trip computer ▲ and ▼ buttons together.
3. Turn the ignition ON while still holding down both buttons.
4. After approx. 3 seconds, release both buttons.
5. The service menu appears and asks you if you want to reset.
6. Press and hold the SET button for more than 3 seconds.
7. Press the MODE button.
8. Turn ignition OFF.

This message is calculated only by distance. Remember that there are additional service requirements, based on time and driving conditions, refer page 4.

The free first service

The 1,500km service is performed free of charge by the Selling Retailer. This service may be carried out by another Holden Retailer provided you have a letter of Introduction from the Selling Retailer. Your Retailer will supply the necessary 'Letter of Introduction' on request.

SERVICING

Service Coupons

Service coupons are provided at the end of this booklet. When each service is performed the coupon is removed so that the following service coupon is readily visible to remind you when the next service is due.

After the service is completed, the owner should check that the service has been validated, by the Retailer stamping and signing the coupon stub. This is important as it not only assists in the determination of Warranty Claims, but enhances the value of the vehicle when selling.

Service coupons are provided up to 195,000 km. After that time the Maintenance Schedule on pages 7 to 9 should be followed.

Your Holden Retailer

When it comes to service, remember that your Holden Retailer has the trained personnel and specialised equipment to correctly service your vehicle. Your Retailer invites you to return for all your service needs both during and after the Warranty Period.

The safety, economy, emission control, performance and reliability of your car cannot be assured unless regular maintenance is performed, preferably by factory-trained technicians at Holden Retailers.

Warranty and service

All maintenance services listed in this Handbook and replacement of service items are the responsibility of the owner and as such are NOT considered, under the provisions of the New Vehicle Warranty, to be rectification of defective material and workmanship. Items such as wheel alignment, necessary adjustments to drive belts, transmission, clutch, parking brake, etc. or any other items which may require servicing due to fair wear and tear are carried out at the owner's cost.

Damage caused by failure to have proper maintenance services carried out by an authorised Holden Retailer or authorised Service Outlet, or in accordance with Holden's specifications, may void your New Vehicle Warranty. It is strongly recommended that you read the 'New Vehicle Warranty' in Chapter 9 of your Owner's Handbook so that you are aware of your Warranty exclusions.

ADDITIONAL SERVICE REQUIREMENTS

The Maintenance Schedule on pages 7 to 9 show the service items for standard driving requirements. Additional service items are required when driving under certain conditions, such as when towing.
The additional services are required while your vehicle is driven under any of the operating conditions listed below.
If you operate under any of these conditions on a one off basis, e.g., holiday trip, then an extra service should be for that time only. As a guide, if you operate continually for a period of one month or 1,000 km under this condition, then this will require additional services.
If you consider that further servicing is required, due to the type of driving or before a long trip, please discuss the situation with the service manager of your Holden Retailer.

The conditions:

A = Frequent short trips (less than 10 km) where the engine does not generally reach operating temperature.
B = Dust, dirt, loose road material.
C = Muddy and wet areas.
D = Cold weather (below 5°C) and when most trips are less than 5 km.
E = Stop-start driving, excessive idling or low speed operation as experienced in inner city driving, e.g., taxi, door to door delivery, police.
F = Caravan or trailer towing.
G = Extended heavy load high speed operation in outside temperatures above 35°C.

Extra services required

Inspect load tray brackets for damage and re-torque fixings every 30,000 km							G
Change engine oil and filter every 6 months	A						
Change automatic transmission fluid and strainer every 30,000 km					E	F	G
Inspect front suspension and steering for leaks, wear or damage every 5,000 km		B	C				
Replace engine filter every 5,000 km or 3 months (whichever comes first)		B					
Change engine oil every 5,000 km or 3 months (whichever comes first)		B		D	E	F	G
Replace air cleaner element every 20,000 km		B					
Inspect and clean park brake linings every 20,000 km		B	C				
Change differential oil every 20,000 km						F	G
Change brake fluid every 12 months if 1,600 kg (or higher) tow bar fitted *						F	
Change power steering fluid every 50,000 km						F	G
Carbon canister: Inspect every 20,000 km and change every 80,000 km		B	C				
Inspect propshaft coupling every 10,000km after 160,000 km of abnormal operating conditions						F	G

* Brake fluid deteriorates with time and should normally be replaced every 27 months. However, heavy duty towing requires fresher fluid due to the higher demand on the brake system. Therefore, brake fluid should be replaced every 12 months if a 1,600 kg (or higher) tow bar is fitted, so that the brake system can cope with the next year's towing requirements.

ADDITIONAL SERVICE REQUIREMENTS cont.

The following record coupons are for additional servicing, refer page 4 for requirements.

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

ADDITIONAL SERVICE REQUIREMENTS cont.

The following record coupons are for additional servicing, refer page 4 for requirements.

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

Date ..... km ..... Servicing Retailer .....
Items performed: .....
.....

MAINTENANCE SCHEDULE

x 1,000 km or months (whichever occurs first)	1.5 1	15 +8	30 +9	45 +9	60 +9	75 +9	90 +9	105 +9	120 +9	135 +9	150 +9	165 +9
Under bonnet												
*Change engine oil and engine oil filter.	-	X	X	X	X	X	X	X	X	X	X	X
Check fluid levels: brake, clutch, power steer, auto trans, washer. Check coolant % with tester and check level (pressure test if low level).	X	X	X	X	X	X	X	X	X	X	X	X
Check battery electrolyte and fluid level, if applicable.	X	X	X	X	X	X	X	X	X	X	X	X
Engine accessory drive belts. Check length indicator and belt condition.	-	-	-	X	X	X	X	X	X	X	X	X
Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.	X	-	X	X	X	X	X	X	X	X	X	X
Drain and refill cooling system with recommended inhibitor and clean fresh water. Clean outside of the radiator A/C condensor.	Change required every 27 months (regardless of kms)											
*Replace engine air cleaner element.	-	-	-	X	-	-	X	-	-	X	-	-
(Supercharger) Check supercharger oil level.	-	-	-	X	-	-	X	-	-	X	-	-
Replace spark plugs (non supercharged).	-	-	-	X	-	-	X	-	-	X	-	-
Replace spark plugs (supercharged only).	-	-	X	-	X	-	X	-	X	-	X	-

*Items marked with the asterisk require additional servicing under some driving conditions. Please refer page 4.

MAINTENANCE SCHEDULE cont.

x 1,000 km	1.5	15	30	45	60	75	90	105	120	135	150	165
or months (whichever occurs first)	1	+8	+9	+9	+9	+9	+9	+9	+9	+9	+9	+9
Under car												
Replace fuel filter and retainer (external type)	-	-	-	X	-	-	X	-	-	X	-	-
Replace fuel filter and seal (in-tank type)	Replace every 210,000 km											
Check final drive oil level.	-	-	-	X	-	-	X	-	-	X	-	-
Check final drive and auto trans for leaks.	X	X	X	X	X	X	X	X	X	X	X	X
*Change auto trans fluid and strainer.	-	-	-	-	-	-	-	X	-	-	-	-
Manual trans. Check oil level.	Oil level check not required											
Manual trans. Check for leaks.	X	X	X	X	X	X	X	X	X	X	X	X
*Change differential oil.	Change not required under normal driving conditions.											
Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.	-	X	X	X	X	X	X	X	X	X	X	X
*Park brake, check linings & drums for wear.	-	-	-	X	-	-	X	-	-	X	-	-
Inspect tyres for irregular wear or damage. Check for damaged wheels. Check air pressures.	X	X	X	X	X	X	X	X	X	X	X	X
*Drain, refill and bleed brake system. Check brake performance when road testing.	Change required every 27 months (regardless of kms) under normal driving conditions											
Drain, refill and bleed clutch system.	Change required every 27 months											
Check all brake and fuel lines and hoses for condition, attachment and routing.	X	X	X	X	X	X	X	X	X	X	X	X
*Inspect front and rear suspension & steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing, leaks, etc. Check condition of all rubber boots and covers.	X	X	X	X	X	X	X	X	X	X	X	X
Inspect exhaust & adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.	X	X	X	X	X	X	X	X	X	X	X	X

*Items marked with the asterisk require additional servicing under some driving conditions. Please refer page 4.

MAINTENANCE SCHEDULE cont.

x 1,000 km	1.5	15	30	45	60	75	90	105	120	135	150	165
or months (whichever occurs first)	1	+8	+9	+9	+9	+9	+9	+9	+9	+9	+9	+9
Under car cont.												
Inspect all constant velocity joints for damage or torn boot and propshaft rubber couplings for tears or splits.	-	X	X	X	X	X	X	X	X	X	X	X
Auto load levelling, if fitted. Change air filter.	-	-	X	-	X	-	X	-	X	-	X	-
Clean and lubricate auto trans shift linkage.	-	-	X	-	-	X	-	-	X	-	-	X
*Check carbon canister for leaks or restrictions.	X	-	-	X	-	-	X	-	-	X	-	-
Inspect air cond. drain tubes for blockage.	-	-	-	X	-	-	X	-	-	X	-	-
Inspect sunroof drain holes for blockage.	-	X	X	X	X	X	X	X	X	X	X	X
Car interior												
Check park brake operations.	-	X	X	X	X	X	X	X	X	X	X	X
Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.	-	X	X	X	X	X	X	X	X	X	X	X
Reset "Service due" light.	X	X	X	X	X	X	X	X	X	X	X	X
Car exterior												
Check operation of all exterior lights.	X	X	X	X	X	X	X	X	X	X	X	X
Lubricate bonnet catch, hinges, rear door check links and lock cylinders.	-	X	X	X	X	X	X	X	X	X	X	X
Check transmitter range of security system.	-	X	X	X	X	X	X	X	X	X	X	X
Road test												
Check braking, steering, engine response & transmission operation. Check operation of cruise control. Check park pawl operation. Check A/C performance. Check neutral start switch.	X	X	X	X	X	X	X	X	X	X	X	X

*Items marked with the asterisk require additional servicing under some driving conditions. Please refer page 4.

SERVICE CHARGES

1,500 km or 1 month
free

at 15,000 km or 8 months from the last service (whichever occurs first)
Labour: 0.7 hours, add 0.3 hours if wheels rotated and balanced
Parts: engine oil filter
Lubricants: engine oil

at 30,000 km or 9 months from the last service (whichever occurs first)
Labour: 0.6 hours for non supercharged, 0.9 hours for supercharged engine, add 0.2 hours if wheels balanced
Parts: engine oil filter, (supercharged only) spark plugs, auto load level air filter (if fitted)
Lubricants: engine oil

at 45,000 km or 9 months from the last service (whichever occurs first)
Labour: 1.4 hours for non supercharged, 1.1 hours for supercharged, add 0.2 hours if wheels balanced
Parts: engine oil filter; (non supercharged) spark plugs; air cleaner element; fuel filter
Lubricants: engine oil

at 60,000 km or 9 months from the last service (whichever occurs first)
Labour: 0.8 hours for non supercharged, 1.1 hours for supercharged, add 0.2 hours if wheels balanced
Parts: engine oil filter,(supercharged) spark plugs, auto load level air filter (if fitted)
Lubricants: engine oil

at 75,000 km or 9 months from the last service (whichever occurs first)
Labour: 0.7 hours, add 0.2 hours if wheels balanced
Parts: engine oil filter
Lubricants: engine oil

at 90,000 km or 9 months from the last service (whichever occurs first)
Labour: 1.4 hours, add 0.2 hours if wheels balanced
Parts: engine oil filter, spark plugs, fuel filter, air cleaner element, auto load level air filter (if fitted)
Lubricants: engine oil

at 105,000 km or 9 months from the last service (whichever occurs first)
Labour: 0.8 hours, add 0.3 for auto, add 0.2 hours if wheels balanced
Parts: engine oil filter, auto strainer and gasket
Lubricants: engine oil, auto trans fluid

SERVICE CHARGES cont.

at 120,000 km or 9 months from the last service (whichever occurs first)

Labour: 0.8 hours for non supercharged, 1.1 hours for supercharged
add 0.2 hours if wheels balanced

Parts: engine oil filter; (supercharged) spark plugs, auto load level air filter (if fitted)

Lubricants: engine oil

at 135,000 km or 9 months from the last service (whichever occurs first)

Labour: 1.4 hours for non supercharged; 1.1 for supercharged
add 0.2 hours if wheels balanced

Parts: engine oil filter, air cleaner element, fuel filter, (non-supercharged) spark plugs

Lubricants: engine oil

at 150,000 km or 9 months from the last service (whichever occurs first)

Labour: 0.7 hours for non supercharged; 1.0 hour for supercharged
add 0.2 hours if wheels balanced

Parts: engine oil filter, (supercharged) spark plugs, auto load level air filter (if fitted)

Lubricants: engine oil

at 165,000 km or 9 months from the last service (whichever occurs first)

Labour: 0.8 hours; add 0.2 hours if wheels balanced

Parts: engine oil filter

Lubricants: engine oil

at 180,000 km or 9 months from the last service (whichever occurs first)

Labour: 1.3 hours add 0.2 hours if wheels balanced

Parts: engine oil filter, air cleaner element, spark plugs, fuel filter, auto load level air filter (if fitted)

Lubricants: engine oil

at 195,000 km or 9 months from the last service (whichever occurs first)

Labour: 0.7 hours, add 0.3 for auto, add 0.2 hours if wheels balanced

Parts: engine oil filter, auto strainer and gasket

Lubricants: engine oil, auto trans fluid

SERVICE CHARGES cont.

In addition to the times, parts and lubricants listed on the previous page, the following operations will be charged for, when required, on a calendar time basis:

Brake fluid must be changed every 27 months (add charge for brake fluid and 0.4 hours labour)

Clutch fluid must be changed every 27 months (add charge for clutch fluid and 0.2 hours labour)

Engine coolant must be changed every 27 months (add charge 0.4 hours labour, engine coolant and pellets).

- The owner is charged for all lubricants and materials used plus labour at the times recommended on the previous pages.

- The repair or replacement of any part found faulty during a service check and not covered by Holden Warranty is added to the charges.

  Where any deficiencies are noted, such items should be reported to the owner/ operator so that the extra work required can be authorised.

- The use of break-in oil, tune up compounds, friction reducing compounds and other supplemental additives are not recommended; their use not only increases operating costs, but may indeed be harmful to your car.

1,500km or 1 month Service Coupon

This coupon should not be removed until the car is presented for service.

Owner's Name Mr. Mrs. Miss. Other.....

Address .....

Town .....

State ..... Postcode .....

Reg. no. ..... Engine no .....

I.S.O.V.I.N. ..... Model .....

Selling Retailer's Stamp & Signature .....

Date of Acquisition .....

This car has been thoroughly checked in accordance with the schedule on the reverse side of this coupon.

Servicing Retailer's Stamp & Signature .....

Servicing Retailer .....

Town ..... State .....

Owner's signature .....

This service is provided FREE of charge.

1,500km or 1 month Service Validation

This car has been thoroughly checked in accordance with the 1,500 km/one month service.

Retailer .....

Service Manager's signature .....

Date ..... Odometer reading .....

Under bonnet

- ❑ Check fluid levels: engine oil, brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Check carbon canister for leaks or restrictions.

Car interior

- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Note that cars fitted with LPG or V8 engines require a different service schedule.

Additional services performed: .....

.....

.....

.....

Service Coupon: at 15,000 km or 8 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.7 hours labour
- engine oil and engine oil filter
- add 0.3 hours if wheels rotated and balanced

Note that cars fitted with LPG or V8 engines require a different service schedule.

There will also be a charge for additional services as requested:

.....

.....

Signature..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Servicing Retailer .....

Date of Service ..... Odometer .....

Signed .....

Service Validation
at 15,000km or 8 months from the last service (whichever occurs first)

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, power steering, clutch, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Additional services performed: .....

.....

.....

Servicing Retailer .....

Date of Service ..... Odometer .....

Signed .....

Service Validation
at 30,000km or 9 months
from the last service
(whichever occurs first)

Service Coupon: at 30,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.6 hours labour for non supercharged engines
- 0.9 hours for supercharged engines
- engine oil and engine oil filter
- auto load level air filter (if fitted)
- spark plugs (supercharged engines only)
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature ..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.
- ❑ (Supercharged) Replace spark plugs.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Auto load levelling, if fitted. Change air filter.
- ❑ Clean and lubricate auto trans shift linkage.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Service Coupon: at 45,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 1.4 hours labour for non supercharged engines
- 1.1 hours for superchaged engines
- engine oil and engine oil filter
- air cleaner element
- spark plugs (non-supercharged engine only)
- fuel filter
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

Signature..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.
- ❑ Replace engine air cleaner element.
- ❑ (Supercharger) Check supercharger oil level.
- ❑ (Non supercharged) Replace spark plugs.

- ❑ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❑ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❑ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Additional services performed: .....

.....

.....

.....

.....

Servicing Retailer.....

Brake fluid changed: YES/NO Clutch fluid changed YES/NO

Coolant changed: YES/NO

Date of Service ..... Odometer .....

Signed.....

Service Validation
at 45,000km or 9 months from the last service (whichever occurs first)

Under car

- ❑ Replace fuel filter and retainer.
- ❑ Check final drive oil level.
- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Parking brake - check linings and drums for wear.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Check carbon canister for leaks or restrictions.
- ❑ Inspect A/C drain tubes for blockage.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Additional services performed: .....

Clutch fluid changed YES/NO .....

Odometer .....

Date of Service .....

Coolant changed: YES/NO .....

Brake fluid changed: YES/NO .....

Servicing Retailer .....

Signed .....

Service Validation
at 60,000km or 9 months from the last service (whichever occurs first)

Service Coupon: at 60,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.8 hours for non supercharged engines
- 1.1 hours for supercharged engines
- engine oil and engine oil filter
- auto load level air filter (if fitted)
- spark plugs (supercharged engines only)
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.
- ❑ (Supercharged) Replace spark plugs.

- ❑ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❑ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❑ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Auto load levelling, if fitted. Change air filter.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Additional services performed:

.....

.....

.....

.....

.....

Servicing Retailer .....

Brake fluid changed: YES/NO Clutch fluid changed YES/NO

Coolant changed: YES/NO

Date of Service ..... Odometer .....

Signed .....

***Service Coupon*: at 75,000 km or 9 months from the last service (whichever occurs first)**

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.7 hours
- engine oil and engine oil filter
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature ..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.

Service Validation
at 75,000km or 9 months from the last service (whichever occurs first)

- ❑ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❑ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❑ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Clean and lubricate auto trans shift linkage.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Servicing Retailer.....

Brake fluid changed: YES/NO

Coolant changed: YES/NO

Date of Service .....

Signed .....

Clutch fluid changed YES/NO

Odometer .....

Additional services performed:

.....

.....

.....

.....

.....

Service Validation
at 95,000km or 9 months
from the last service
(whichever occurs first)

Service Coupon: at 90,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 1.4 hours
- engine oil and engine oil filter
- spark plugs
- fuel filter
- auto load level air filter (if fitted)
- air cleaner element
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

Signature.....Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.
- ❑ Replace engine air cleaner element.
- ❑ (Supercharger) Check supercharger oil level.
- ❑ Replace spark plugs

- ❒ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❒ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❒ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Under car

- ❑ Replace fuel filter and retainer.
- ❑ Check final drive oil level.
- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Parking brake - check linings and drums for wear.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Auto load levelling, if fitted. Change air filter.
- ❑ Check carbon canister for leaks or restrictions.
- ❑ Inspect A/C drain tubes for blockage.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Additional services performed: .....

.....

.....

.....

.....

Servicing Retailer .....

Brake fluid changed: YES/NO Clutch fluid changed YES/NO

Coolant changed: YES/NO

Date of Service ..... Odometer .....

Signed .....

Service Validation
at 105,000km or 9 months from the last service (whichever occurs first)

Service Coupon: at 105,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.8 hours
- add 0.3 for auto transmission
- auto trans strainer, gasket and fluid (if auto trans fitted)
- engine oil and engine oil filter
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus (for V6 engines only) coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature ..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.

- ❑ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❑ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❑ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Change auto trans fluid and strainer.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Service Coupon: at 120,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.8 hours for non supercharged engines
- 1.1 hours for supercharged engines
- engine oil and engine oil filter
- auto load level air filter (if fitted)
- spark plugs (supercharged engines only)
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature ..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.
- ❑ (Supercharged) Replace spark plugs.

- ❑ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❑ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❑ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Additional services performed:

.....

.....

.....

.....

.....

Servicing Retailer.....

Brake fluid changed: YES/NO Clutch fluid changed YES/NO

Coolant changed: YES/NO

Date of Service ..... Odometer .....

Signed.....

Service Validation
at 120,000km or 9 months from the last service (whichever occurs first)

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Auto load levelling, if fitted. Change air filter.
- ❑ Clean and lubricate auto trans shift linkage.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Additional services performed: .....

.....

.....

.....

.....

.....

Servicing Retailer .....

Brake fluid changed: YES/NO Clutch fluid changed YES/NO

Coolant changed: YES/NO

Date of Service ..... Odometer .....

Signed .....

Service Validation
at 135,000km or 9 months from the last service (whichever occurs first)

Service Coupon: at 135,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 1.4 hours for non supercharged engines
- 1.1 hours for supercharged
- spark plugs (non supercharged engines only)
- air cleaner element
- fuel filter
- engine oil and engine oil filter
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

Signature ..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.
- ❑ Replace engine air cleaner element.
- ❑ (Supercharger) Check supercharger oil level.
- ❑ (Non supercharged) Replace spark plugs.

- ❑ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❑ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❑ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Under car

- ❑ Replace fuel filter and retainer.
- ❑ Check final drive oil level.
- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Parking brake - check linings and drums for wear.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Check carbon canister for leaks or restrictions.
- ❑ Inspect A/C drain tubes for blockage.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Additional services performed:

.....

.....

.....

.....

.....

Servicing Retailer .....

Brake fluid changed: YES/NO Clutch fluid changed YES/NO

Coolant changed: YES/NO

Date of Service ..... Odometer .....

Signed .....

Service Validation
at 150,000km or 9 months from the last service (whichever occurs first)

Service Coupon: at 150,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.7 hours for non supercharged engines
- 1.0 hours for supercharged engines
- spark plugs (supercharged engines only)
- auto load level air filter (if fitted)
- engine oil and engine oil filter
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature ..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.
- ❑ (Supercharged) Replace spark plugs.

- ❑ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❑ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❑ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Auto load levelling, if fitted. Change air filter.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Additional services performed: .....

.....

.....

.....

.....

Servicing Retailer .....

Brake fluid changed: YES/NO Clutch fluid changed YES/NO

Coolant changed: YES/NO

Date of Service ..... Odometer .....

Signed .....

Service Validation
at 165,000km or 9 months from the last service (whichever occurs first)

Service Coupon: at 165,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.8 hours
- engine oil and engine oil filter
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.

- ❒ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❒ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❒ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Clean and lubricate auto trans shift linkage.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Service Validation
at 180,000km or 9 months from the last service (whichever occurs first)

Servicing Retailer .....
Brake fluid changed: YES/NO
Coolant changed: YES/NO
Date of Service .....
Signed .....

Clutch fluid changed YES/NO
Odometer .....

Additional services performed:
.....
.....
.....
.....
.....

Service Coupon: at 180,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 1.3 hours
- air cleaner element
- spark plugs
- auto load level air filter (if fitted)
- fuel filter
- engine oil and engine oil filter
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, auto trans, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ (Supercharger) Check supercharger oil level.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.

- ❒ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❒ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❒ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

- ❑ Replace engine air cleaner element.
- ❑ Replace spark plugs.

Under car

- ❑ Replace fuel filter and retainer.
- ❑ Check final drive oil level.
- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Parking brake - check linings and drums for wear.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Auto load levelling, if fitted. Change air filter.
- ❑ Check carbon canister for leaks or restrictions.
- ❑ Inspect A/C drain tubes for blockage.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.

Additional services performed: .....

.....

.....

.....

.....

Servicing Retailer .....

Brake fluid changed: YES/NO Clutch fluid changed YES/NO

Coolant changed: YES/NO

Date of Service ..... Odometer .....

Signed .....

Service Validation
at 195,000km or 9 months
from the last service
(whichever occurs first)

Service Coupon: at 195,000 km or 9 months from the last service (whichever occurs first)

I authorise performance of the services specified on this coupon. I understand that I will be charged for the time, parts and lubricants, as listed:

- 0.7 hours
- add 0.3 for auto transmission
- engine oil and engine oil filter
- auto trans strainer, gasket and fluid (if auto trans fitted)
- if brake fluid changed add 0.4 hours plus brake fluid
- if clutch fluid changed add 0.2 hours plus brake fluid
- if engine coolant changed add 0.4 hours plus coolant plus coolant pellets
- add 0.2 hours if wheels balanced

Note that cars fitted with LPG or V8 engines require a different service schedule. There will also be a charge for additional services as requested:

.....

.....

Signature ..... Date .....

NOTE : If the owner/driver of this car has changed since the last service please complete the change notice at the introduction of your Owner's Handbook.

Under bonnet

- ❑ Change engine oil and engine oil filter.
- ❑ Check fluid levels: brake, clutch, power steering, washer. Check coolant inhibitor % with tester and check level (pressure test if level is low).
- ❑ Check battery electrolyte and fluid level.
- ❑ Engine accessory drive belts. Check length indicator and belt condition.
- ❑ Check for signs of deterioration and/or leaks from engine, fluid reservoirs, air ducts, all hoses and clamps.

- ❑ Brake fluid. Change every 27 months (regardless of km) Drain, refill and bleed brake system. Check brake performance when road testing.
- ❑ Clutch fluid. Change every 27 months (regardless of km) Drain, refill and bleed clutch system. Check clutch performance when road testing.
- ❑ Engine Coolant. Change every 27 months (regardless of km) Drain and refill cooling system (with recommended coolant and clean fresh water). Clean outside of the radiator and A/C condenser.

Under car

- ❑ Check final drive and auto trans for leaks.
- ❑ Manual transmission. Check for leaks.
- ❑ Change auto trans fluid and strainer.
- ❑ Inspect front and rear disc pads for wear and discs for surface condition. Rotate wheels. Balance if required.
- ❑ Inspect tyres for irregular wear or damage, check for damaged wheels. Check air pressures.
- ❑ Check all brake and fuel lines and hoses for condition, attachment and routing.
- ❑ Inspect front and rear suspension and steering system for damaged, loose or missing parts, signs of wear or lack of lubrication. Inspect power steering lines and hoses for condition, attachment and routing leaks, etc. Check condition of all rubber boots and covers.
- ❑ Inspect exhaust system and adjacent underbody. Look for damaged, missing or out-of-position parts, open seams, holes or loose connections. Run car and check for exhaust leaks.
- ❑ Inspect all CV joints for damage or torn boots and propshaft rubber couplings for tears or splits.
- ❑ Inspect sunroof drain holes for blockage.

Car interior

- ❑ Check park brake operation.
- ❑ Seat belt inspection. Check webbing condition, buckle operation and retractor mechanism operation.
- ❑ Reset "Service Due" light.

Car exterior

- ❑ Check operation of all exterior lights.
- ❑ Lubricate bonnet catch, door hinges, rear door check links and all lock cylinders.
- ❑ Check transmitter range of security system.

Road test

- ❑ Check for braking, steering, engine response and transmission operation. Check operation of cruise control. Check park lock operation. Check A/C performance. Check neutral start switch.